

### ZOOM ADSL X6 (lights on front)



Light 1: Power: Should be green and solid

Light 2: Ethernet: Should be green and blinking as data is transferred

Light 3: WLAN: Should be green and blinking as data is transferred

Light 4: DSL: Should be green and solid

Light 5: Internet: Should be green and blinking as data is transferred. If the light is red, modem has lost its settings; please call our office for assistance.



- Ethernet cable (yellow in this picture) goes from one of the 4 ports to your computer/device.
- Base cord (gray in this picture) goes from single DSL port the DSL jack on the wall.
- Black cord is for power